## **Camera setting**

After power the unit, please check the home menu/Set



Rear view

| Settings        |  |
|-----------------|--|
| Sound           |  |
| Effect Set      |  |
| Brightness      |  |
| System settings |  |
| Language        |  |
| Rear view       |  |
| NetWork         |  |
| SystemInfo      |  |
|                 |  |
|                 |  |

If your car has factory backup camera or not install any aftermarket

**Rear view** Add on Camera Original Camera ◄ 360 Camera Reversing assistance line • **Display Radar Information Reversing front** 🔘 yes o no Ĵ ×.... 📚 🚷 ₹ 🛛 Č  $\bigtriangleup$ 


cameras, please select "Original Camera"

If you install aftermarket backup camera, please select "360 Camera"



## **Camera connection**

NOTE the camera cord is provided only when you buy the backup camera



from us.

 Red wire-connect to "BACK/REVERSE" wire (blue color) from main harness.

(This is reverse trigger wire, if you connect incorrectly, the screen will not change when reverse the car)

2. Yellow RCA jack, connect to "**Backacar VIDEO IN**" jack (yellow color) of navigation unit.

(This is the camera video input jack, if you connect incorrectly, the screen will display no signal when reverse the car)

- 3. Black wire-connect to **NEGATIVE of reverse light** (NOT license plate light).
- 4. Red wire-connect to **POSITIVE of reverse light** (NOT license plate light).